




QTY	12	12	-	-	33	5/8\"/>
	2	2	-	-	33	LAG 5/8\"/>
	4	4	-	-	28	LAG 1/2\"/>
	14	14	-	-	31	CARBIDE BOLT 1/2\"/>
	-	-	-	-	30	INTERPAPER (OPTIONAL)
	1	-	ABS75	-	29	46KV 1200AMP LH JAW ASSY
	1	-	ABS75	-	28	46KV 1200AMP LH BLADE ASSY
	2	-	ABS74	-	27	46KV 1200AMP RH JAW ASSY
	2	-	ABS76	-	26	46KV 1200AMP RH BLADE ASSY
	-	1	ABS25	-	25	46KV 600AMP LH JAW ASSY
	-	1	ABS77	-	24	46KV 600AMP LH BLADE ASSY
	-	2	ABS24	-	23	46KV 600AMP RH JAW ASSY
	-	2	ABS76	-	22	46KV 600AMP RH BLADE ASSY
	16	16	SEE ORDER	-	21	INSULATOR
	2	2	ABS21	ALUM	20	PHASE GUIDE ASSY
	3	3	ABS25	ALUM	19	PIPE LEVER ASSY
	1	1	ABS47	-	18	THRUST BEARING ASSY
	1	1	003030	GALV	17	THRUST BEARING W/5 BRKT
	-	-	ABS030	GALV	16	2\"/>
	-	-	15	-	15	2\"/>
	1	1	003030	GALV	14	2\"/>
	2	2	ABS29	GALV	13	2\"/>
	2	2	ABS28	ALUM	12	PIPE GUIDE ASSY
	-	-	-	-	11	-
	2	2	003030	GALV	10	2\"/>
	-	-	9	-	9	OPERATOR HANDLE ASSY
	1	1	ABS24	GALV	8	OPERATOR HANDLE ASSY
	1	1	ABS29	ALUM	7	LATCHING PLATE ASSY
	1	1	003079-10BK	ALUM	6	OPERATOR W/5 BRKT
	3	3	003030	GALV	5	3/4\"/>
	16	16	ABS23	GALV	4	3/4\"/>
	3	3	ABS23	ALUM	3	PIVOT ASSY - 1 LEVER (2 x 423) (1 x 483)
	3	3	00087320	GALV	2	INSULATOR FEEDSTAP
	3	3	ABS11	ALUM	1	1/2\"/>




PIPE GUIDE ASSY



OPER MTG BRKT DETAIL



OPERATOR HANDLE DETAIL



46 KV BLADE ASSY  
RIGHT HAND SHOWN, LEFT HAND TYPICAL